



When installing the Vivid throat light on your machine it is imperative to adhere to the following instructions. Doing so will result in optimal installation and longevity of the product.

Machine Preparation

- ✓ Ensure the room temperature is not below 70°F.
- ✓ Use the provided alcohol wipes to thoroughly clean the underside of the machine arm. Failure to have the surface of the machine, where the light will be installed, completely free of debris and oil will result in the light not adhering correctly.

Light Preparation

- ✓ There are two strips of adhesive located on the underside of the light.



- ✓ Remove the red backing from each of the adhesive strips.



Accessing Throat Light Plug

- ✓ Locate the two handlebar light screws and remove each using a 5/64" allen wrench.



- ✓ Plug the throat light into the plug indicated by the red circle.



- ✓ Place the plugs and handlebar light back into the handlebar and replace the two screws using the 5/64" allen wrench.

Attaching Throat Light

- ✓ Adhere the throat light to the underside of the machine throat. Press the light onto the machine firmly and hold for at least 30 seconds.
- ✓ It is ok to use the light immediately after installation but please ensure you do not strain the bond for the first 72 hours after installation.