



Vision 2.0 Application Version 1.2.0 Improvements


M-V2-0003A1 – Rev 00

OVERVIEW

The release of Vision 2.0 application version 1.2.0 added three new features to the Vision 2.0 machine. This document outlines the details of those improvements.

MY STITCH™ BUTTONS: H-LOCK TOGGLE & V-LOCK TOGGLE

The My Stitch™ Buttons feature offers adjustment while stitching, fingertip access to key features and assistance with common functions. Each of the four My Stitch™ Buttons can be customized and set to change functions and speeds on the fly as well as access key functions such as tie off. Now the vertical and horizontal channel locks are accessible during quilting.




Each of the four buttons can now be configured to include the following functions:

Function	Function Description
H-Lock Toggle	When pressed, if the horizontal channel lock is not engaged, it will engage. Pressing the button a second time will disengage the horizontal channel lock.
V-Lock Toggle	When pressed, if the vertical channel lock is not engaged, it will engage. Pressing the button a second time will disengage the vertical channel lock.


THE H-LOCK TOGGLE AND V-LOCK TOGGLE ARE ACCESSABLE DURING STITCHING.

Using the H-Lock Toggle and V-Lock Toggle features:


- Touch the My Stitch™ Button desired to set.




- Select either the H-Lock Toggle or the V-Lock Toggle.



- Press the assigned handle button. Notice the appropriate channel lock engages limiting stitching to one direction, and the channel lock icon at the top of the screen changes to the locked position.




- Press the assigned button again. Notice the channel lock disengages, allowing stitching in all directions, and the channel lock icon at the top of the screen changes to the open position.



SINGLE STITCH FUNCTION

The Single Stitch Icon delivers a single stitch with the touch of the icon allowing on-screen access to the single stitch when all the My Stitch Buttons are programmed to use other settings.



To use the Single Stitch Function:


- Touch the **Single Stitch** icon. Notice the machine delivers a single stitch.

NOTE: THE ICON ON THE SCREEN DOES NOT REMOVE THE ABILITY TO SET A HANDLE BUTTON TO SINGLE STITCH IF THAT IS YOUR PREFERENCE. THIS CHANGE ONLY PROVIDES AN ON-SCREEN ALTERNATIVE TO A PHYSICAL BUTTON.

SINGLE STITCH ACCESS IN BASTE MODE:

A change has been made that now allows the single stitch to function when stitching in Baste mode. In previous versions, the single stitch would not function when stitching was enabled in any mode.

Baste mode functions like stitch regulation on a large scale, stitching from ¼ inch up to 4 inches per stitch. This helps to stabilize the quilt. Now a single stitch can be delivered while basting.



To engage Baste Mode:

- Touch the **Baste icon** in the top ribbon.
- Notice the stitching mode is indicated in the mode section in the middle of the screen.

To take a single stitch while basting:

- Set the My Stitch™ Buttons to Single Stitch. Then use the handle button to single stitch while basting.
or
- Touch the Single Stitch icon on the user interface.

NOTE: THE STITCH LENGTH WILL RESTART AFTER THE SINGLE STITCH IS TAKEN. IF BASTING AT TWO STITCHES PER INCH AND A SINGLE STITCH IS TAKEN, THE FOLLOWING STITCH WILL BE TWO INCHES FROM THE SINGLE STITCH.