


Elevate Smart Sync

Smart Sync gives you the ability to sync selective portions of your pattern library. When Enabled, only patterns in your Elevate Collection will be synced to your Elevate Stitcher. If you have more than 1,000 patterns then this is recommended. More than 1,000 may induce tablet lag.


- Log into your PatternCloud account
- Go to **My Cloud, Stickers** (as shown)
- You should see an Elevate listed. (If you do not go to your tablet's Elevate app, Pattern Manager, Sync, click Register then Sync Patterns.)
- Check **Elevate Selective Sync**



- Go to **My Cloud, Patterns** pick a pattern you want to Sync
- Click **Edit Tags**



- In the Collections field type "**Elevate**", then click **+Collection**



- Click **Save Changes**. In the Elevate app, sync and if this pattern is not already on your tablet it will sync, but other new patterns not in the "**Elevate**" collection will not sync.